


**KitchenAid®****OVEN PARTS**

For Models: KEMC307KBL05, KEMC307KWH05, KEMC307KBT05, KEMC307KSS05  
(Black) (White) (Biscuit) (S.Steel)

30" BUILT-IN ELECTRIC  
DOUBLE OVEN  
THERMAL CONVECTION LOWER  
CRISPWAVE MICROWAVE UPPER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN PARTS

For Models:KEMC307KBL05, KEMC307KWH05, KEMC307KBT05, KEMC307KSS05  
(Black) (White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	7	8303099	Top Chassis	31	3196176	Screw
	8300653	Installation Instructions	8	4449809	Screw	32	4449154	Screw
	8304066	Use & Care Guide (Oven)	9	4452158	Tube, Vent	33	9760677	Deflector, Vent
	8304067	Use & Care Guide (Microwave)	10	4452163	Lens, Light	34	4451619	Vent, Center
	4451052	Cooking Guide (Label)	11	4448972	Oven Light Assy	35	4450038	Screw
	4450786	Cooking Guide (Label)	12	4452164	Bulb, Light	36	3400832	Screw
	4450786	Cooking Guide (Label)	13	4452337	Insulation	37	9759243	Thermostat 120c (Temp.) SPST
	8303852	Tech Sheet (Oven)	14	9759060	Frame, Front	43	9759713	Base, Chassis
	4449264	Easy Set Guide	15	4455382	Gasket, Door	49	4448933	Retainer, Gasket
	3191638	Safer Cooking Tips	16	4452152	Bracket, Mounting	50	4451747	Cover, Back
	9759133	Safer Cooking Tips	17	4448444	Grommet	51		Trim, Bottom
2		Trim, Side	19	4451478	Support, Insulation		4455443	Black
	4455430	RH Black	20	4451605	Cap, Spacer		4455445	White
	4455432	RH White	21		Rail, Side		4455447	Biscuit
	4455434	RH Biscuit		4450583	Right Side		4455147	S.Steel
	4452083	RH S.Steel		4450584	Left Side	52	4451756	Chassis, Back
	4455431	LH Black	22	4449040	Screw	53	4452260	Spacer, Foam
	4455433	LH White	23	4449743	Screw	54	4456145	Vent, Control
	4455435	LH Biscuit	24		Screw			
	4452084	LH S.Steel		8281236	Black			
3		Hinge Reciever		694091	S.Steel			
	4455605	Left Hand	25	4455641	Side, Chassis (R.H. & L.H.)			
	4455606	Right Hand	26	4452234	Back, Chassis			
4	4448520	Bumper, Door	27		Liner, Oven (Not serviceable)			
6	4452490	Spacer, Foam	28	9752759	Relay			
			29	4455636	Sensor			
			30	4449845	Bracket, Support			


## FOLLOWING PARTS NOT ILLUSTRATED

### INSULATION

4449316 Insulation, Wrap  
4450365 Insulation, Back

# CONTROL PANEL PARTS

For Models: KEMC307KBL05, KEMC307KWH05, KEMC307KBT05, KEMC307KSS05  
(Black) (White) (Biscuit) (S.Steel)




Illus. No.	Part No.	DESCRIPTION
1	4452604	Panel, Control Black
	4452605	White
	4452974	Biscuit
	4451791	S.Steel
2	8302346	Assy, Control
3	4449745	Screw
4		Assy, Membrane
	8302681	Black
	8302682	White
	8302683	Biscuit
	8302688	S.Steel
5	3400832	Screw
6	4451592	Filter
7	4451632	Bracket, Filter
8	4449809	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN DOOR PARTS

For Models: KEMC307KBL05, KEMC307KWH05, KEMC307KBT05, KEMC307KSS05  
(Black) (White) (Biscuit) (S.Steel)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	9759413	Door Liner	12	4455391	Door Glass, Assy Black	14	4455803	Bracket, Handle R.Hand
2	9760575	Hinge, Door R.Side		4455390	White		4455804	L.Hand
3	9760576	L.Side		4455395	Biscuit	15	9759229	Bracket(2nd Glass)
4	4449259	Glass, Inner		4452316	S.Steel	16	9759230	Bracket(3rd Glass)
5	4451722	Insulation, Door	13	4452502	Door Handle Black	19	4457103	Shield, Heat
6	4457132	Retainer, Glass		4452503	White	21	4452326	Seal, Door Top
7	4449809	Screw		4452871	Biscuit	22	4457114	Shield, Vent (Btm)
8	9759225	Glass, Inner		4455851	S.Steel	23		Retainer, Glass-Clip
9	4449743	Screw					4450863	Black
10	3196184	Screw					4450864	White
	4449040	Screw					4452119	Biscuit
							4451432	S.Steel
						24	9759228	Glass, Inner

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# LATCH PARTS

For Models: KEMC307KBL05, KEMC307KWH05, KEMC307KBT05, KEMC307KSS05  
(Black) (White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust
2	4455178	Elbow, Vent-Top
3	8300791	Bracket, Combo Chassis
5	4455177	Elbow, Vent-Bottom
6	4451758	Seal, Foam
8	4450408	Baffle, Rear
9	4449154	Screw
10	9760888	Latch, Motorized
16	6610168	Blower
17	4449809	Screw
19	4449906	Ext Filler
20	4455191	Plate, Blower Service

## IMPORTANT PRODUCT SAFETY INFORMATION

**ADVISE CONSUMERS OF AN ELECTROCUTION HAZARD WITH DO – IT – YOURSELF REPAIRS OF MICROWAVE OVENS.**


The U.S. Consumer Product Safety Commission warns against do – it – yourself repairs of microwave ovens. Microwave ovens use high voltage which makes it particularly hazardous for consumers to remove the cover and touch electrical parts.

**STRONGLY RECOMMEND THAT CONSUMERS HAVE PROFESSIONALS REPAIR MICROWAVE OVENS.**

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# INTERNAL OVEN PARTS

For Models: KEMC307KBL05, KEMC307KWH05, KEMC307KBT05, KEMC307KSS05  
(Black) (White) (Biscuit) (S.Steel)




Illus. No.	Part No.	DESCRIPTION
1	4456104	Element, Broil
2	4449154	Screw
3	4457277	Grill, Broiler
4	4457276	Pan, Broiler
5	3181534	Rack, Roasting
6	4448717	Rack, Oven
7	4452155	Element, Bake
8	4448881	Nut, Hex
9	4451583	Convection, Motor
10	4452226	Blade, Fan
11	4448882	Washer, Lock
12	4452227	Nut
13	4451355	Jack, Meat Probe
14	4448948	Probe, Meat
15	4455037	Tray, Bake
17	4450039	Cover, Bake Tray
18	4449809	Screw
20	4452157	Element, Convection
21	4448418	Cover, Fan

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET AND STIRRER PARTS

For Models: KEMC307KBL05, KEMC307KWH05, KEMC307KBT05, KEMC307KSS05  
(Black) (White) (Biscuit) (S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET AND STIRRER PARTS

For Models:KEMC307KBL05, KEMC307KWH05, KEMC307KBT05, KEMC307KSS05

(Black)

(White)

(Biscuit)

(S.Steel)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	4375299	Bracket, Capacitor	24	4375191	Crisp Plate	41	4375330	Door Strap
2	4375313	Screw	25	4375020	Capacitor	42	4375331	Plate, Grill
3	4375037	Rubber Ring	26	4375072	Magnetron	43	4375332	Bracket
4	4375038	Screw	27	4375321	Fuse	44	4375333	Fan Cap
5	4375314	Air Duct, Magnetron	28	4375231	Block, Fuse	45	4375334	Fan Cap Bottom
6	4375253	Support, Tube	29	4375278	Motor, Blower	46		Switch Holder
7	4375254	Plug, Ceramic	30	4375279	Thermostat		4375335	Left
8	4375255	Bushing	31	4375079	Thermostat		4375336	Right
9	4375256	Reflector	32	4375281	Thermostat	47	4375337	Isolation Plate
10	4375257	Chamber, Reflector	33	4375282	Q Tube Assembly	48	4375338	Cover Plate
11	4375315	Damper	34	4375286	Transformer	49	4375339	Door Plate
12	4375260	Duct, Inlet	35	4375344	Ring, Turntable	50	4375340	Inner Frame
13	4375316	Insulation, Switch	36	4375345	Shaft, Turntable	51		Side Plate
14	4375322	Fan Wheel	37		Hinge, Door		4375341	Left
15	4375317	Duct, Air		4375324	Right		4375342	Right
16	4375264	Block, Slide		4375323	Left	52	4455915	Turntable
17	4375248	Cover Plate, Upper	38	4451009	Torsion Spring	53	4375346	Switch
18	4375035	Screw		4451009	R.Hand	54	4375347	Motor, Turntable
19	4375318	Lens, Lamp		4452396	R.Hand (S.Steel)	55	4375348	Lamp
20	4375319	Spring		4452395	L.Hand	56	4375349	Rectifier
21	4375320	Reflector	39		Bracket, Hinge	57	4375350	Cable
22	4378400	Pan Handle		4375327	Left	58	4375351	Holder, Lamp
23		Rack		4375328	Right			
	4375276	Broiling (Tall)	40	4375329	Inlet			
	4452220	Convection (Short)						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



# MICROWAVE COMPARTMENT PARTS

For Models: KEMC307KBL05, KEMC307KWH05, KEMC307KBT05, KEMC307KSS05  
 (Black) (White) (Biscuit) (S.Steel)




Illus. No.	Part No.	DESCRIPTION
1	4452551	Support Rails Right Side
	4452552	Support Rails Left Side
2	4449809	Screw
3	4452548	Rear Channel
4	4449809	Screw
5	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP VENTING PARTS

For Models:KEMC307KBL05, KEMC307KWH05, KEMC307KBT05, KEMC307KSS05  
(Black) (White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1	4450378	Cover, Top
2	4448935	Baffle, Blower
3	4450920	Blower
4	4449809	Screw
5	4452104	Transformer, (Lights)
6	4451634	Exhaust Duct
7	4450027	Bracket, Duct
8	4449964	Grommet
9	4454949	Holder, Fuse
10	4454976	Fuse


Illus. No.	Part No.	DESCRIPTION
11	4449868	Block, Terminal
12	4452559	Side, Combo
13	4456145	Vent, (Control Panel)
14	4451597	Side, Control Top Right
	4451598	Left
15	4452244	Back, Control
16	4450551	Cover, Top Rear

Illus. No.	Part No.	DESCRIPTION
17	4448664	Clamp
18	4452367	Cover, Top Front
19	4455038	Transformer, Control Panel
20	4452247	Plate, Cover
21	4451934	Suppressor
22	313806	Screw
23	4449154	Screw
24	3400080	Screw
25	4450038	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# MICROWAVE DOOR PARTS

For Models: KEMC307KBL05, KEMC307KWH05, KEMC307KBT05, KEMC307KSS05  
(Black) (White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
9	4448937	Glass, Middle
10	8303556	Frame, Door
11	4450038	Screw
13	4449141	Bracket, Mounting
	4449142	Right Side
	4449142	Left Side
14	4449809	Screw

Illus. No.	Part No.	DESCRIPTION
15	4449083	Filler, Side
	4449086	Right Side
	4449086	Left Side
16	4452502	Handle, Door
	4452502	Black
	4452503	White
	4452871	Biscuit
	4455851	S.Steel

Illus. No.	Part No.	DESCRIPTION
17	4452211	Glass, Outer
	4452789	Black
	4452789	White
	4452995	Biscuit
	4452259	S.Steel
23	4452331	Bracket, Handle
24	3196184	Screw
25		Retainer, Glass-Clip
	4450863	Black
	4450864	White
	4452119	Biscuit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS (NOT INCLUDED)

For Models:KEMC307KBL05, KEMC307KWH05, KEMC307KBT05, KEMC307KSS05  
(Black) (White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

## PAINT, TOUCH-UP (1/2oz.)

	72017	White
	261869	Cord Brown
	72032	Black
	4392899	Biscuit

## PAINT, SPRAY

	350930	White
	261900	Citrine White
	830864	Black
	4392901	Biscuit

## ADHESIVE

	591014	Adhesive Loctite (1/3 oz.)
	482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

## SPLICING WIRES--25FT.

### LENGTH

	242828	Wire (12 Ga. 150 c Black)
	242820	Wire (14 Ga. 150 c Black)
	242821	Wire (14 Ga. 150 c Blue)
	242822	Wire (14 Ga. 150 c Brown)
	242830	Wire (14 Ga. 200 c Brown)
	242823	Wire (14 Ga. 150 c Green)
	242824	Wire (14 Ga. 150 c Orange)
	242825	Wire (14 Ga. 150 c Red)
	242831	Wire (14 Ga. 200 c Red)
	242827	Wire (14 Ga. 150 c Yellow)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

## FOLLOWING PARTS NOT ILLUSTRATED

	4378944	Filler Kit (BL)
	4378945	Filler Kit (WH)
	4378946	Filler Kit (AL)

## WIRING HARNESS PARTS

	8301909	Harness, Latch
	8303837	Harness, Main Filter
	4449809	Screw
	8301922	Harness, Main
	4450831	Ground (M/W)
	4450800	Screw, Ground
	4449809	Screw
	4450950	Conduit, Combo
	313438	Clip, Harness
	98997	Clip, Harness
	4452400	Lead, Ground
	4454835	Tie, Cable

## Miscellaneous

	4448950	Screw, Install (4)
	814381	Hinge Pin Kit
	8537055	SS Cleaner

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST